


STATE STREET / MIDDLE STREET CABINET RELOCATION - 08/23/2018



NOTES:

- 1. REMOVE OLD CABINET FOUNDATION AS NECESSARY.
- 2. REPLACE EXISTING LANDSCAPING WITH NEW SIDEWALK CONSTRUCTED AS SHOWN USING THE PROVIDED STANDARD CROSS SECTION DETAIL (SIDEWALK X-SECTION).
- 3. PROVIDE NEW SIEMENS (EAGLE) TYPE P CABINET FULLY FURNISHED WITH NEW SIEMENS M60 EQUIPMENT. PROVIDE CONCRETE FOUNDATION 12" ABOVE GRADE, NO RISER UNDER CABINET. SEE PROVIDED SPECIFICATION (ITEM 616.191).
- 4. PROVIDE NEW CABLING AS NECESSARY TO AVOID ANY UNDERGROUND SPLICING.
- 5. PROVIDE 6' OF NEW CAST IRON RADIUSED TIP DOWN PANELS IN 7'x3'x6" THICK CONCRETE PAD. ALL OTHER SIDEWALK MATERIALS ARE BRICK.
- PROVIDE PRICING FOR BRICK SIDEWALK SEPARATELY, PAID FOR BY THE SQUARE FOOT. SEE PROVIDED SPECIFICATION (ITEM 608.5) AND DETAIL (SIDEWALK X-SECTION).